


COST OF UNEXPECTED REPAIRS



**LIBERTY
SHIELD**™

ADDITIONAL BENEFITS

Roadside Assistance

You will receive 24/7 assistance with lockouts, tire changes, jump starts, fluid delivery and towing when you call toll free 800-418-9836.

Car Rental

You will receive rental car reimbursement for all qualified covered repairs.*

Trip Interruption

If you are away from home and your vehicle has a mechanical breakdown that is covered, we will reimburse you for meals and lodging.*

Transferability

If you sell your vehicle with coverage remaining, you can transfer the coverage to the next owner.*

No Deductible

If you return to the dealer that sold you our contract, you will not have to pay a deductible.*

*Refer to your contract for specific information.

VEHICLE SERVICE CONTRACT COVERAGE OPTIONS

	LEVEL 3 - Exclusionary*	LEVEL 2 - Comprehensive*	LEVEL 1 - Powertrain Plus*
Engine	✓	✓	✓
Transmission	✓	✓	✓
Drive Axle	✓	✓	✓
Fuel Systems	✓	✓	
Air Conditioning	✓	✓	
Heating	✓		
Brake Systems	✓	✓	
Seals and Gaskets	✓	✓	✓
Fluids for Covered Repair	✓	✓	✓
Electrical *Major Components	✓	✓	
Electrical *Specialty Components	✓		
Suspension	✓	✓	
Steering Components	✓	✓	
All Original Factory Installed Components Other than what is Excluded	✓		

LEVEL 1 - POWERTRAIN PLUS

Engine

- Cylinder Block
- Cylinder Head
- Timing Case/Cover
- Timing Chain
- Timing Belt
- Tensioners
- Gears
- Sprockets
- Guides
- Serpentine Belt Tensioner
- Vibration Damper
- Oil Pump
- Intake Manifold
- Flywheel with Starter Ring Gear
- Core Plugs
- Valve Covers
- Oil Pan
- Turbocharger
- Supercharger & Internal Parts
- Wastegate Actuator
- Oxygen Sensor
- Mass Air Flow Sensor
- ERG Valve
- Crank Sensor
- Cam Sensor
- Seals and Gaskets

Engine Cooling System

- Water Pump and Housing
- Fan Clutch
- Thermostat
- Radiator
- Heater Core & Recovery Tank

Automatic Transmission

- Case and Internal Parts
- Bell Housing
- Pan
- Torque Converter
- Drive/Flex Plate
- Range Switch
- Speed Sensors
- Pressure Sensors
- PRNDL Position Switch
- Control Module
- Valve Body
- Mechatronics Unit
- Conductor Plate
- Servo Assemblies
- Cooler

Manual Transmission

- Main Shaft
- Counter Shaft
- Gears

- Chain
- Input Shaft
- Hub Assemblies
- Synchronizers
- Shift Rails
- Shift Fork
- Bearings

Front Wheel Drive

- Transaxle Case
- Axle Shaft
- Constant Velocity Joints & Boots
- Differential Cover
- Transaxle Speed Sensors
- Transaxle Solenoid Assembly
- Transaxle Electronic Controller
- Wheel Bearings/Hub

All Wheel Drive

- Power Transfer Unit
- Viscous Coupler
- Axle Housing
- Constant Velocity Joints & Boots
- Drive Shaft
- Axle Shaft
- Differential Carrier Assembly
- Output Ball Bearing
- Output Flange
- End Cover
- Overrunning Clutch
- Vacuum Motor
- Torque Tube
- Pinion Spacer & Shim
- Wheel Bearings/Hub Assemblies

Rear Wheel Drive

- Axle Housing
- Axle Shafts & Bearings
- Drive Shaft Assemblies
- Drive Shaft Center Bearings
- Universal Joints & Yokes
- Wheel Bearings/Hub Assemblies

Four- Wheel Drive

- Transfer Case
- Control Module
- Shift Mode Assembly
- Axle Housing
- Axle Shafts
- Drive Shaft & Assemblies
- Center Bearings
- Universal Joints
- 4 x 4 Hubs
- Yokes
- Wheel Bearings
- Hub Assemblies
- Disconnect Housing Assembly

LEVEL 2 - COMPREHENSIVE

Suspension

- Upper & Lower Control Arms
- Upper & Lower Bushings
- Ball Joints
- Leaf Springs
- Air & Coil Springs

Steering Components

- Power Steering Pump
- Power Steering Motor
- Gear Box
- Rack & Pinion
- High Pressure Lines
- Steering Box & Rack & Pump Housing

Brake Components

- Power Brake Booster
- Master Cylinder
- Wheel Cylinders
- Calipers
- ABS Hydraulic Components
- Proportioning Valve
- ABS Wheel Speed Sensors
- ABS Control Mode

Electrical Components

- Starter Motor
- Solenoid
- Alternator/ Mounting Bracket
- Voltage Regulator
- Wiper Motor Front & Rear
- Cooling Fan Motor
- Distributor
- Ignition Coils

- Power Window Motors/ Regulators/Switches
- Power Seat Motors
- Power Seat Track Assembly
- Power Door Lock Actuators & Switches
- Power Trunk/ Tailgate Actuator & Motor
- Power Sunroof Motor
- Convertible Top Lift Motor & Pump
- Power Mirror Motors
- Manually Operated Switches
- Ignition Control Module
- Cruise Control Assembly

Air Conditioning & Refrigerant

- Compressor
- Clutch
- Pulley
- Mounting Bracket
- Condenser
- Accumulator/Receiver Drier
- Evaporator
- Refrigerant

Fuel

- Fuel Pump
- Fuel Injectors
- Injection Control Module
- Lift Pump
- Transfer Pump
- MAP/Air Charge Temperature Sensor
- Intake Manifold Pressure Sensor
- Throttle Position Sensor

LEVEL 3 - EXCLUSIONARY

Almost Everything

- Nearly all OEM-installed mechanical and electronic components are covered. Check your contract for exclusions.

Fuel

- Fuel Sender Assembly
- Waste Gate
- Intercooler
- Supercharger Pulley
- Pressure Regulator
- Fuel Tank
- Accelerator Pedal Assembly

Interior Climate & Comfort

- Idler Pulleys & Bearings
- Serpentine Belt Tensioner
- Expansion Valve
- Orifice Tube
- AC Pressure Switches
- Blower Motor & Fan
- Heater Core
- Heater Control Valve
- Control Cables
- Ducts
- Plenum Doors
- Blower Motor Resistor
- Condensor Cooling Fan Motor
- Manual Climate Control Head
- Metal Lines

Accessories

- Heated Seat Grids
- Rear Window Defogger/ Defroster
- Memory Seat Motors/ Switches/Sensors/Module
- Memory Steering Motors/ Switches/Module

Body Hardware

- Hood & Trunk Latches & Cables
- Hood & Trunk Hinges
- Hood & Trunk Springs & Torsion Bars
- Hood & Trunk Hydraulic Lift Supports
- Door Hinges
- Door Handles
- Glovebox Assembly
- Ignition Lock Assembly
- Door Jam Switches
- Seat Track Assembly

Electrical Components

- Electronic Control Module (ECM)/Computer
- Horn & Horn Relay

TECH-SHIELD OPTION

- Head Unit
- Display
- LCD Screen
- DVD/Blu-ray Player
- GPS/Navigation
- Radio/CD Player
- Rearview Back-up Camera
- Bluetooth Connectivity
- Phone Communication Systems
- Alarm Systems
- Keyless Entry Transmitter & Receiver
- Early Collision Detection System
- Self Park Assist System
- Tire Pressure Monitoring System
- Cruise Control
- Instrument Cluster
- Speedometer
- Odometer
- Fuel Gauge
- Tachometer
- Volt & Amp Gauge
- Temperature Gauge

ECO-SHIELD OPTION

- Spark Plug Wires
- Coil to Spark Plug Boots & Connectors
- Vapor Canisters
- Emission Canisters
- Positive Crankcase Ventilation Valve
- Distributor Cap & Rotor
- PCV Valve
- Gas Cap
- Smog Pumps
- Catalytic Converter
- Muffler
- Exhaust Pipes
- High Voltage Drive Batteries



**LIBERTY
SHIELD**™